


# Yealink T54W Quick Guide

## Deskphone Features





## Feature Description

1. **Line keys**—enables you to select a phone line, view calls on a line, or quickly call a favorite contact.
2. **Soft keys**—enables you to select context-sensitive keys that display along the bottom of the screen.
3. **Navigation keys**—transfer an active call to a contact.
4. **Cancel key**—holds an active call or resumes a held call.
5. **Volume keys**—adjusts the volume of the handset, headset, and speaker.
6. **Voicemail key**—enables you to access voicemail messages.
7. **Redial key**—enables you to dial the last called number or extension.
8. **Mute/Unmute key**—mutes audio during calls and conferences.
9. **Headset key**—enables you to place and receive calls through a headset.
10. **Redial key**—enables you to dial the last called number or extension.
11. **Voicemail key**—enables you to access voicemail messages.
12. **Speakerphone key**—enables you to place and receive calls using the speakerphone.

## Placing a call

---



### Dial the number and do one of the following:

- Lift the receiver.
  - Press  to use the headset.
  - Press  to use the speakerphone.
- 

## Answering a call



---

### Options:

- Lift the receiver.
  - Press  to answer a call via headset.
  - Press  to answer a call via speakerphone.
- 


## Placing a call on hold

---

- Press the **Hold** soft key or   while on an active call.
- 

## Retrieving a held call

---

- Press the **Retrieve** soft key or  to retrieve a held call.
- 

## Starting a Conference call

---

1. While on an active call, press the **Conference** soft key.
  2. Dial the extension of the other party that you would like to add to the call.
  3. Once the other party answers, press the **Conference** soft key to merge the two calls.
- 

## Retrieving a Parked Call

---

- Press , followed by the park location.
- 

## Transferring a call

---



### Warm Transfer:

1. While on an active call, press the **Transfer** soft key.
2. Dial the number of the other party.
3. When the destination party answers, provide the information, and confirm that they would like to take the call.
4. Press the **Send** soft key.

### Blind Transfer:

1. While on an active call, press the **Transfer** soft key.
2. Dial the extension of the other party.
3. Press the **B Transfer** soft key.

### Voicemail Transfer:

1. Press the **Transfer** soft key.
  2. Press the **Blind** soft key.
  3. Dial   plus the extension number of the voicemail where you want to transfer the call.
- 





## Parking a call

---

### Option 1:

1. While on an active call, press the **More** soft key until the **Park** soft key is displayed.
2. Press the **Park** soft key.
3. Listen to the prompt indicating that the call has been parked. The prompt will also announce the extension where the call is parked.
4. Note the park location. Example \*802.

### Option 2:

1. While on an active call, press    .
  2. Listen to the prompt indicating that the call has been parked. The prompt will also announce the extension where the call is parked.
  3. Note the park location. Example \*802.
-

---

## Paging

---

- Press   , then follow the prompt.
- 

---

## Initiating an Intercom call



---

- Press   , then follow the prompt.
- 

---

## Hot Desking





---

- Press the **Login** soft key then follow the prompt.
  - Enter your extension number, then press .
  - Enter your voicemail pin, then press .
- 

---

## Recording a call

---

- While on an active call, press   to start the recording.
  - Press   to end the recording.
-